


Material für meisterliche Motive

Satin Baryta Paper (4848)
295 g/m² satin

Druck-Einstellungen Epson Stylus Pro 9890

Die vorhandenen Profile gelten nur für Originaltinten und sind nur einer Einstellung im Druckertreiber zugeordnet. Sollten Sie davon abweichende Einstellungen verwenden, erfolgt die Farbwiedergabe möglicherweise nicht korrekt.

Wählen Sie bitte im Druckertreiber unter dem Punkt *Haupt Einstellungen* die im Screenshot erkennbaren Medieneinstellungen.



Wählen Sie bitte im sich öffnenden Fenster unter *Papierkonfiguration* bei Walzenabstand „Breit“.

The image shows a software dialog box titled "Papierkonfiguration". It contains several adjustable parameters:

- Farbdichte:** A slider ranging from -50 to 50, with a value of +0 (%).
- Trocknungszeit pro Druckkopfbewegung:** A slider ranging from 0 to 50, with a value of 0 (0.1Sek.).
- Papiereinzugseinstellung:** A slider ranging from -70 to 70, with a value of +0 (0.01%).
- Papieransaugung:** A slider with positions Standard, -1, -2, -3, and -4.
- Papierstärke:** A numeric input field set to 3 (0.1mm).
- Walzenabstand:** A dropdown menu currently set to "Breit", which is circled in red.
- Rollenpapier-Rückspannung:** A dropdown menu set to "Auto".

At the bottom of the dialog are four buttons: "Standard", "OK", "Abbrechen", and "Hilfe".