T-Shirt Transfer - 4232 / 4234

Application instructions using hand press



Transfer your favourite designs, photos or logos - lets get started:

PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE BEGINNING

- All fabrics must contain a minimum of 50% cotton
- Wash fabric before transferring
- Avoid fingerprints both before and after printing
- Curled or damaged sheets should not be used

Transfer	
Hand press temperature	180°C
Image preparation	Dark fabrics - Trim the image down, rounding of all edges - leaving a 3-4 mm white edge all the way around. Peel the film from the release liner and place image facing up on the fabric. Light / white fabrics - Trim the image down, rounding of all edges - leaving a 3-4 mm edge all the way around. Position image facing down on the fabric.
Hand press	15-20 secs
Removing the tissue paper	Leave fabric to cool completely before removing the tissue paper.

Aftercare tips	
Washing & Drying	• Wait at least 24 hrs after transfer printing before washing • Wash inside-out • Machine settings: Max. 30°C / 1000 rotations/min • Do not use softener or bleach detergents • Take straight out of the machine when the cycle is finished • Drying: Tumble drier with cool settings
Iroining	Maintain excellent colours by ironing after every wash - always with baking paper. Never iron the unprotected transfer. **Do not use steam!**

Printing and printer settings - 09/2019

N.B
This information corresponds to the best of our current knowledge and is a guide, without obligations, to our products and their application possibilities. Our findings do not exonerate personal testing and checks. We reserve the right to adapt our information to serve product improvements.

Sihl GmbH
Kreuzauer Str. 33
52355 Düren/Germany

www.sihl.com